

5"



Hide & Seek GINGERBREAD™



AGES  
3+  
PLAYERS  
2+



CONTENTS:  
1 Silly Gingerbread

### SETUP

Flip the switch on the back of the SILLY GINGERBREAD to the ON position.

**NOTE:** There are three positions on this power switch: Demo, OFF, and ON. Make sure you're flipping it to the ON position (not DEMO) to get the whole experience!

### HOW TO PLAY

Pick a player to be the first to hide the Silly Gingerbread! Let's call this person the "Hider."

### HIDING THE GINGERBREAD

The Hider hides the Gingerbread and presses the "FIND ME" button. Once they're done hiding, the Hider lets everyone know that they can begin looking.

**HEADS UP:** It's a good idea to move really far away from the hiding spot before you let everyone start looking. You don't want to give away any hints too early!

### FINDING THE GINGERBREAD

All players (except the Hider) must search for the Silly Gingerbread! At this point, the Silly Gingerbread will start saying hilarious phrases and making funny noises to give clues about the hiding spot. Keep your eyes and ears open!



### WINNING

The first player to find the Silly Gingerbread is the winner! Press the FIND ME button to hear a fun party song as a reward. Take some time to sing and dance along before setting up for the next round!

The winner gets to be the Hider for the next round!

**TIP:** When you're done with this frightfully delightful hide and seek game, we suggest flipping the switch to the OFF position.

### Battery Replacement:



PLEASE READ THE INSTRUCTIONS BEFORE USE.  
KEEP THE INSTRUCTIONS, SINCE IT CONTAINS IMPORTANT INFORMATION.  
PRODUCT IS SURFACE WASH ONLY, DO NOT SUBMERGE.

#### BATTERY REPLACEMENT:

- 2 AA (INCLUDED AND REPLACEABLE).
- BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY. (+ AND -).
- THE REPLACEMENT OF THE BATTERIES TO BE MADE BY AN ADULT FOLLOWING THE INSTRUCTIONS.
- EXHAUSTED BATTERIES ARE TO BE REMOVED FROM THE TOY.
- FOR OPTIMAL PERFORMANCE, USE ONLY ALKALINE BATTERIES.

#### BATTERY CAUTIONS:

- DO NOT MIX OLD AND NEW BATTERIES.
- DO NOT MIX ALKALINE, STANDARD (CARBON-ZINC), OR RECHARGEABLE BATTERIES.

**THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.** OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.  
CAN ICES-3 (B) / NMB-3 (B)

Questions or comments? [customerservice@Relatable.com](mailto:customerservice@Relatable.com)

Copyright © 2025 Relatable PO Box 2100, New York, NY 10013  
Falcon House Business Centre, 3 Eagle Road, Plymouth, PL7 5JY, UK  
Kroonwiel 2, Weert, 6003 BT, Netherlands  
[Relatable.com](http://Relatable.com)

7"